


©2019 TENCATE GEOSYNTHETICS




TYPICAL MIRAFI® TM14S PLACEMENT

SLOPE SHALL BE OVERBUILT AND CUT BACK TO FINAL GEOMETRY PRIOR TO PLACEMENT OF TOPSOIL, IF UNABLE TO ACHIEVE SATISFACTORY COMPACTION AT SLOPE FACE.

MIRAFI® TM14S ROLL SIZE IS 12-FT WIDE x 70-FT LONG. UNROLL MIRAFI® TM14S DOWN THE SLOPE FACE. INSTALL MIRAFI® TM14S USING AN ANCHOR TRENCH AT THE TOP AND BOTTOM OF THE SLOPE. AT THE TOP OF THE SLOPE EXTEND MIRAFI® TM14S ONE FOOT BEYOND THE TOP OF SLOPE AND INSERT INTO A MINIMUM 6-INCH WIDE BY 12-INCH DEEP ANCHOR TRENCH BACKFILLED WITH COMPACTED SOIL. AT THE BOTTOM OF THE SLOPE EXTEND MIRAFI® TM14S INTO THE SAME SIZE ANCHOR TRENCH AT THE TOE OF THE SLOPE.

OVERLAP MIRAFI® TM14S A MINIMUM OF 6-INCHES ALONG ROLL EDGES. USE U-SHAPED SOIL STAPLES TO PIN MIRAFI® TM14S TO THE SLOPE FACE. INSTALL STAPLES ALONG THE ROLL OVERLAP AND IN THE ROLL CENTER. USE A MAXIMUM STAPLE SPACING OF 3-FT ON CENTER.



TYPICAL SECTION - SLOPE REINFORCEMENT - MIRAFI® TM14S FACED



365 SOUTH HOLLAND DRIVE
PENDERGRASS, GEORGIA 30567
TEL: (706) 693-2226
WWW.TENCATEGEO.US

NOTE: THE STANDARD DETAILS ILLUSTRATED IN THESE DRAWINGS ARE FOR INFORMATION AND EVALUATION PURPOSES ONLY AND ARE NOT FOR CONSTRUCTION. PROJECT SPECIFIC CALCULATIONS, SHOP DRAWINGS AND SPECIFICATIONS, SIGNED AND SEALED BY A STATE REGISTERED LICENSED ENGINEER, ARE REQUIRED FOR CONSTRUCTION.

REINFORCED SOIL SLOPE
REINFORCED SLOPE WITH MIRAFI® TM14S

STANDARD DETAIL
NOT FOR CONSTRUCTION

DATE : 4/24/19

MIRAFI® TM14S
TYPICAL CROSS
SECTION

SHEET OF
W7 10