



- EXCAVATE FOR LEVEL BASE TO A LENGTH ADEQUATE FOR REINFORCEMENT DESIGN LENGTH.




STEP 1

- WRAP MIRAMESH GR REINFORCEMENT OVER COMPACTED FILL.
- STAPLE OR STAKE MIRAMESH GR TO HOLD IN PLACE.




STEP 3

- PLACE BACKFILL ON UPPER COURSE IN MAXIMUM LIFTS OF 9 INCHES, AND COMPACT TO 95% OF STANDARD PROCTOR.
- REMOVE TEMPORARY FORM FOR LOWER COURSE.




STEP 5

- CHECK LEVEL OF BASE.
- CHECK ALL LINE, GRADE, AND CURVES.
- PLACE FORM AT FRONT OF REINFORCED MASS. DRAPE TENCATE MIRAMESH GR OVER FORMWORK. PLACE MIRAGRID XT SOIL REINFORCEMENT OVER MIRAMESH GR.
- PLACE BACKFILL IN MAXIMUM LIFTS OF 9 INCHES, AND COMPACT TO 95% OF STANDARD PROCTOR.




STEP 2

- PLACE TEMPORARY FORM FOR NEXT COURSE.
- DRAPE TENCATE MIRAMESH GR OVER FORMWORK. PLACE MIRAGRID XT SOIL REINFORCEMENT OVER MIRAMESH GR.




STEP 4

- REPEAT STEPS 2 THRU 4 UNTIL SLOPE IS AT REQUIRED HEIGHT.
- PLACE FINAL BACKFILL AND TOPSOIL.



STEP 6



WOOD FORM DETAIL



365 SOUTH HOLLAND DRIVE
PENDERGRASS, GEORGIA 30567
TEL: (706) 693-2226
WWW.TENCATEGEO.US

NOTE: THE STANDARD DETAILS ILLUSTRATED IN THESE DRAWINGS ARE FOR INFORMATION AND EVALUATION PURPOSES ONLY AND ARE NOT FOR CONSTRUCTION. PROJECT SPECIFIC CALCULATIONS, SHOP DRAWINGS AND SPECIFICATIONS, SIGNED AND SEALED BY A STATE REGISTERED LICENSED ENGINEER, ARE REQUIRED FOR CONSTRUCTION.

REINFORCED SOIL SLOPE
WRAP FACE RSS DETAILS

STANDARD DETAIL
NOT FOR CONSTRUCTION
DATE : 4/24/19

WRAP FACE
INSTALLATION

SHEET OF
W6 10